

Azur 851C IR Remote Control Codes

851C CD player Commands

System Code = 20 (RC-5 Code)

Key	Command code dec.
Open/Close	45
Power Toggle	12
Power on	50
Power off	51
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
-/-- / 10+	14
0	0
Prog	36
Skip left	33
Play	53
Skip right	32
<<	44
Stop	54
>>	43
Info	21
Pause	48
LCD Bright	40
LCD Dim	41
LCD Off	42
Menu	52
Select / Enter	55
Filter	56
LCD test	57
Remain	61
Random	28
Repeat	29

851A amplifier commands

System Code = 20 (RC-5 Code)

Key	Command code dec.
Source Up	8
Source 1	4
Source 2	5
Source 3	3
Source 4	1
Source 5	2
Source 6	0
Source 7	6
Source 8	7
Vol +	16
Vol -	17
Mute toggle	13
Mute	50
Unmute	51

Information in this document has been carefully checked for accuracy; however, Cambridge Audio's policy is one of continuous improvement, therefore design and specifications are subject to change without prior notice. If you notice any errors please feel free to email us at: support.cambridgeaudio.com

This document contains proprietary information protected by copyright. All rights are reserved. No part of this document may be reproduced by any mechanical, electronic or other means, in any form, without prior written permission of the manufacturer.

© Copyright Cambridge Audio Ltd 2008